



# **KRYPTONITE**

## **FORD SUPER DUTY WHEEL BEARING INSTALLATION**

- **APPLY HIGH TEMP BEARING GREASE TO THE O-RING BEFORE INSTALLATION**
  - **SPINDLE BOLTS: 133 FT/LBS**
  - **CALIPER BOLTS: 166 FT/LBS**

**CONTINUED ON BACK**

- **WHEEL STUDS: 140-155 FT/LBS  
(VARIES BASED ON MODEL YEAR/  
WHEEL MANUFACTURER)**



 **FOLLOW US**  
@kryptoniteproducts

**KRYPTONITEPRODUCTS**.COM