

2013+ Dodge Ram LD & HD Boss Grille Installation Instructions

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-357-9261
Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)
Contact your PUTCO dealer for other quality accessories.

Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS:	
Description	Qty.
Boss Grille	1
Upper Mounting Brackets (Right and Left)	2
Lower Alignment Tabs	2
1/4"-20 x 3/4" SS bolt	10
1/4"-20 SS Lock Nut	10
1/4" SS Washer	20
Only for Lighted Grille (below)	
10" Luminix Light (Installed)	2
Wiring Harness	1
Switch	1
Light Bar Installation Instructions	1

Tools Needed:

- 10mm Wrench
- Flat Head Screw Driver
- 7/16" Wrench
- 5/32" Hex Key
- Dremel Tool or File

Grille Installation

1. Remove Grille from packaging. Check to see if all parts from above table of kit contents are included.
2. Use a 5/32" hex key and 7/16" wrench to install the 6 provided nuts, bolts and washers. Install the two upper mounting brackets to the 6 mounting tabs on the back side of the grille. (Refer to Figure 1 - Passenger side shown.)



Figure 1

LIMITED 90 DAY WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.

3. Use the remaining 4 nuts, bolts and washers to install the two lower alignment tabs. (Refer to Figure 2)



Figure 2

4. Remove plastic cover by removing 6 retaining clips. Use a flat head screw driver to remove center pin followed by outer retainer. (Refer to Figure 3)
5. Once cover is removed, remove the top 4 grille screws with 10mm wrench. (Refer to Figure 4)



Figure 3



Figure 4

6. The grille will still be secured at the bottom with push clip retainers. To remove, pull grille firmly forward and away from the truck. (Refer to Figure 5)



Figure 5

LIMITED 90 DAY WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.

7. Remove the rubber flaps from in front of the radiator by removing 12 plastic retaining clips with a flat head screw driver. (Locations shown below.)



Figure 6 - Before



Figure 7 - After

8. **For HD install only:** Using a file or a Dremel Tool, widen the lower tab receiving hole to 13/16". (Refer to Figure 8)



Figure 8

9. Set new grille into vehicle. Align the lower tabs to corresponding hole location. Align tabs as needed using the 5/32" hex key and 7/16" wrench. Push the lower part of the grille towards the vehicle to get tabs to lock into the holes.
10. Reinstall 4 - 10mm bolts to secure the grille. Adjust upper brackets and grille as needed to align the grille in the vehicle. (Refer to Figure 9)



Figure 9

For Lighted grilles, refer to Wiring Installation on Light Bar Installation Instructions for wiring instructions.

LIMITED LIFETIME WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.